






TGB6055 Operating Guide

Walk-behind Battery Scrubber Dryer



To start the machine, turn the key (1) then pull the start triggers (2) with the deck down, this will start the brush spinning.



With the machine running press the Water On/Off button and the Vacuum On/Off button as required.