






TBL6055T NX1K Operating Guide

Walk-behind Battery Scrubber Dryer



To start the machine, turn the key (1) set the direction switch to forward (2) set the speed control (3).



Press the Water On/Off button and the Vacuum On/Off button as required.



Pull the start triggers (2) with the deck down, this will start the brush spinning.