


TT1535 Operating Guide Compact Scrubber Dryer











FloorCare














To start the machine, pull both triggers in (1) then press down the start button (2) with the deck down, this will start the brush spinning.

With the machine running press the Water On/Off button and the Vacuum On/Off button as required.

(f) numatic.com (+44 (0)1460 68600



Numatic.com

