

CTB370NX After Use Maintenance

Extraction Battery Vacuum



The machine needs to be flushed with clean water after use to avoid blockages and increase the lifespan of the product. Before disassembly/storage depressurise any residual fluid by holding the trigger and allowing excess fluid to escape.

