




## CRG8072 Operating Guide Ride-On Scrubber Dryer















To start the machine, turn the key (1) set the direction switch to forward (2) set the speed control and water flow rate(3).

With the machine running press Vacuum On/Off button press and hold the Brush Engage button.

then press the accelerator peddle to operate

mumatic.com **(**+44 (0)1460 68600





