


## TGB3045/4045/4055 Operating Guide


Compact and Cordless Scrubber Dryer




















down the start button (2) with the deck down, this will start the brush spinning.



With the machine running press the Water On/Off button and the Vacuum On/Off button as required.







