







TBL8572 Operating Guide

Walk-behind Battery Scrubber Dryer



To start the machine, turn the key (1) set the direction switch to forward (2) set the speed control (3).



Wet water flow by turning the dial and the Vacuum On/Off button as required.



Pull the start triggers with the deck down, this will start the brush spinning.