






CRL8055 NX1K Operating Guide


Ride-On Scrubber Dryer



To start the machine, turn the key (1) set the direction switch to forward (2) set the speed control and water flow rate(3).



With the machine running press Vacuum On/Off button



Press the accelerator peddle to operate